

**Product information on solid fuel local space heaters  
according to Commission regulation (EU) 2015/1185**



<b>Model</b>	HWAM 4340
<b>Direct heat output [kW]</b>	6,0
<b>Indirect heating functionality</b>	No
<b>Indirect heat output [kW]</b>	-
<b>Type of heat output/room temperature control</b>	Two or more manual stages, no temperature control

<b>Space heating performance at nominal heat output</b>		
<b>Fuel</b>	<b>Preferred fuel</b>	<b>Seasonal space heating energy efficiency [%]</b>
Wood logs with moisture content 12-18 %	Yes	70
<b>Emissions</b>	<b>mg/m<sup>3</sup> (13% O<sub>2</sub>)</b>	
Particulate matter (PM)	25	
Organic gaseous compounds (OGC)	41	
Carbon monoxide (CO)	1125	
Nitrogen oxides (NO <sub>x</sub> )	149	

<b>Characteristics when operating with the preferred fuel only</b>	
Nominal heat output [kW]	6,0
Electric power consumption nominal heat output [kW]	-
Electric power consumption minimum heat output [kW]	-
Electric power consumption standby mode [kW]	-
Useful efficiency at nominal heat output [%]	80
Energy efficiency index	106
Energy efficiency class	A

**Specific Precautions during Assembling, Installing & Maintenance:**

See installation instructions for more information

**Product End-of-Life/Recycling:**

To dispose of the stove after the product life has expired, please observe the following information

- Dispose of the items correctly i.e. separate the parts to be disposed of in material groups
- Always dispose of items in a way that is as sustainable as possible and that is in line with the current environmental protection, reprocessing/recycling and disposal technology